

## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

736108 Coffee Table

#### ITEM: **736108 ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

**15 MINUTES** 

### PARTS IDENTIFICATION

Α **TOP** 




1PC

**LEG** В

3

(4 mm - BLK)



#### **HARDWARE IDENTIFICATION**


**BOLT** 6PCS (6 mm - BLK) **FLAT WASHER** 6PCS 2 (8 mm - BLK) **ALLEN WRENCH** 

1PC


# ITEM: **736108**ASSEMBLY INSTRUCTIONS



#### STEP 1



#### STEP 2



## STEP 3 COMPLETE






PAGE 3 OF 3

**COASTERFURNITURE.COM** 

ITEM: **736108** 





Note: Dimension tolerance ±5%