

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



701686 3PC OCCASIONAL SET

REVISION 0 : 06/09/2014 REVISION 1 : 12/17/2018 REVISION 2 : 08/15/2019 REVISION 3 : 08/09/2022 REVISION 4 : 02/17/2023

PAGE 1 OF 11

COASTERFURNITURE.COM

ITEM:701686




ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

MARNING! 1. Don't attem 2. This produc

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately. 2. This product is for home use only and not intended for commercial establishments.



ITEM:701686

						COASTER	
Z	HARDWARE IDENTIFICATION					FINE FUI	RNITURE
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	5	BOLT M 6 x 28mm SR		48 PCS
2	WOODEN DOWEL Ø 8x30mm		48 PCS	6	PLASTIC FEET Ø 15mm	Ð	12 PCS
3	CAM BOLT Ø 7x35.5mm SR		50 PCS	7	STICKER Ø 20mm		9 PCS
4	CAM LOCK Ø 15x12mm SR		50 PCS				

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

