

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life





COASTERFURNITURE.COM

ITEM:881291(B1&B2)

ASSEMBLY INSTRUCTIONS



COASTERFURNITURE.COM


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.



PAGE 2 OF 7

ITEM:881291(B1&B2)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME


30 MINUTES


HARDWARE IDENTIFICATION


Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 881291 (B2)

1	LONG BOLT (M6 x 45mm - BLK)	Contraction (O)	10PCS
2	MEDIUM BOLT (M6 x 35mm - BLK)	Co de la construcción de la cons	4PCS
3	SHORT BOLT (M6 x 25mm - BLK)	Company (O)	10PCS
4	LOCK WASHER (1.6 x 12mm - BLK)		24PCS
5	FLAT WASHER (1.2 x 18mm - BLK)		24PCS
6	ALLEN WRENCH (M4 x 65mm - BLK)		1PC
7	WOOD DOWEL (10 x 30mm - BRW)		4PCS

COASTERFURNITURE.COM







ITEM:881291(B1&B2)

ASSEMBLY INSTRUCTIONS STEP 7

