


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

150505 Dining Set

ITEM: 150505

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

Remove hardware from box and sort by size.
 Please check to see that all hardware and parts are present prior to start of assembly.

3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
 This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME


30 MINUTES

PARTS INDENTIFICATION


No	DESCRIPTION & FIGURE	QTY
140		~
Α	TABLE TOP	1pc
В	TABLE LEG	2pcs
С	TABLE TOP APRON	2pcs
D	TABLE TOP SUPPORT	4pcs
Е	CHAIR SEAT	4pcs
F	CHAIR BACK	4pcs
G	CHAIR BACK LEG	4pcs
Н	CHAIR LEFT LEG	4pcs
I	CHAIR RIGHT LEG	4pcs
J	CHAIR FRONT STRETCHER	4pcs
K	CHAIR MIDDLE STRETCHER	4pcs

HARDWARE PACKAGE:

No	DESCRIPTION	FIGURE	QTY
1	BOLT (longest)	① M6×60mm	4pcs
2	BOLT (longer)	③ M 6×50mm	4pcs
3	BOLT (long)	() () () () () () () () () () () () () ()	8pcs
4	BOLT (short)	① M6×30mm	40pcs
5	BOLT (shorter)	③ M6×12mm	40pcs
6	STUD	0111111111111111111111111111111111111	4pcs
7	NUT	☐ ⑥ M6×17mm	8pcs
8	ALLEN KEY (4mm)		2pcs




STEP 2




ITEM: 150505

STEP 3





STEP 4



PAGE 4 OF 5

COASTERFURNITURE.COM

ITEM: 150505

COASTER®

STEP 5

COMPLETE

