




ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

223117
Bench

REVISION 0: 09/14/2019
REVISION 1: 03/21/2023

ITEM:223117

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intend for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

A SEAT



1PC


B SHELF



1PC


C BOTTOM CONNECTING ROD

2PCS




D TOP CONNECTING ROD

2PCS



E SIDE FRAME



2PCS

HARDWARE IDENTIFICATION

1 BOLT

1/4"x1/2"



8PCS

2 BOLT

1/4"x5/8"



8PCS

3 BOLT

1/4"x3/4"



6PCS

4 WASHER

1/4"



6PCS

5 SPRING WASHER

1/4"



6PCS

6 SCREW

4x1/2"



8PCS

7 ALLEN KEY

4mm




1PC

ITEM:223117

ASSEMBLY INSTRUCTIONS




STEP 1




2		8PCS
7		1PC

STEP 2



1		8PCS
7		1PC

STEP 3




6		8PCS
7		1PC





ITEM:223117

ASSEMBLY INSTRUCTIONS




STEP 4




3		6PCS
4		6PCS
5		6PCS
7		1PC

STEP 5 COMPLETE



ITEM:223117



Note: Dimension tolerance $\pm 5\%$