



*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

509524

SOFA

ITEM: 509524

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.







WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 15 MINUTES

PARTS IDENTIFICATION


A		BASE	1PC
B		BACK CUSHION	2PCS
C		LEG	4PCS
D		MIDDLE LEG	1PC

ITEM: 509524




ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2



STEP 3



ITEM: 509524



Note : Dimension tolerance $\pm 5\%$

COASTERFURNITURE.COM