

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

223372 *Nightstand* ITEM: 223372

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

A NIGHTSTAND



1PC

B LEG



4PCS

HARDWARE IDENTIFICATION

1 BOLT (M6 x 15MM - RBW)



12PCS

2 ALLEN WRENCH (M4 x 65MM - BLK)



1PC

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provided this item.

ITEM: 223372


COASTER

ASSEMBLY INSTRUCTIONS


STEP 1



STEP 2



STEP 3 COMPLETE






PAGE 3 OF 3



Inner Size of Drawer: 17.75"W X 15.00"D X 5.00"H X 0.50"T



Note: Dimension tolerance ±5%