

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

SOFA TABLE

930010

ITEM : 930010



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

Z-HARDWARE

B1: TOP



MIRROR CABINET 1PC

B2: LEG



LEG 1PC


1		BOLT 8x35MM	4PCS
2		WASHER Φ20x2MM	4PCS
3		ALLEN KEY 30x80MM	1PC

HARDWARE PACK IS LOCATED IN 930010 (B1)



ITEM : 930010

ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2



ITEM : 930010



COASTERFURNITURE.COM

Note: Dimension tolerance $\pm 5\%$