



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

SOFA TABLE

951786

ITEM : 951786



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

B1: TOP


A TABLE TOP



1PC

B2: BASE

B BASE



1PC

Z-HARDWARE

C BOLT 8X35MM



4PC

D WASHER ϕ 20X2MM



4PC

E ALLEN KEY 30X80MM




1PC

HARDWARE PACK IS LOCATED IN 951786 (B1)


ITEM : 951786

ASSEMBLY INSTRUCTIONS



STEP 1





STEP 2



STEP 3



ITEM : 951786



COASTERFURNITURE.COM

Note: Dimension tolerance $\pm 5\%$