


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

953422

SOFA TABLE

ITEM : 953422



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.








ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

Z-HARDWARE

B1: TOP		
A TABLE TOP		1PC
B2: BASE		
B BASE		1PC


1 BOLT 8X35MM		4PCS
2 WASHER φ20X2MM		4PCS
3 ALLEN KEY 30X80MM		1PC

HARDWARE PACK IS LOCATED IN 953422 (B1)



ITEM : 953422


ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2





Note: Dimension tolerance $\pm 5\%$

