




# ***ASSEMBLY INSTRUCTIONS***

## ***COASTER FINE FURNITURE***



*Fine Furniture for every stage of life*

**722898**

**Coffee Table**

REVISION 1: 11/26/2019

REVISION 2 : 09/01/2022

ITEM:722898

# ASSEMBLY INSTRUCTIONS



## ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intend for commercial establishments.



ASSEMBLY TIME

20 MINUTES


## PARTS IDENTIFICATION

A TABLE TOP




1PC

B LOWER LEG FRAME



1PC

C UPPER LEG FRAME



1PC

## HARDWARE IDENTIFICATION

1 BOLT

1/4"x7/8"



9PCS

2 SPRING WASHER

1/4"



9PCS

3 WASHER

1/4"



9PCS

4 ALLEN KEY

4mm




1PC

ITEM: 722898

# ASSEMBLY INSTRUCTIONS




## STEP 1



1		1PC
2		1PC
3		1PC
4		1PC


## STEP 2




1		8PCS
2		8PCS
3		8PCS
4		1PC

## STEP 3

COMPLETE



ITEM:722898



**Note:** Dimension tolerance  $\pm 5\%$