


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

931214
End Table

REVISION 1: 12/27/2019
REVISION 2 : 09/02/2022

ITEM: **931214**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intend for commercial establishments.




ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

A TOP

1PC



B BOTTOM FRAME

1PC



C LEG


3PCS



HARDWARE IDENTIFICATION

1 BOLT


1/4"x5/8"



6PCS

2 BOLT

1/4"*1-1/4



3PCS

3 ALLEN KEY

4mm





1PC


ITEM: **931214**

ASSEMBLY INSTRUCTIONS





STEP 1


1		6PCS
3		1PC





STEP 2

COMPLETE

2		6PCS
3		1PC



ITEM:931214



Note: Dimension tolerance ±5%