

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

950059 Console Table

REVISION 0 : 03/05/2016 REVISION 1 : 06/01/2019 REVISION 2 : 04/18/2023

PAGE 1 OF 2

COASTERFURNITURE.COM

ITEM: 950059

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

A TOP



1PC

B BOTTOM PANEL



1PC

C UPPER LEG



4PCS

D LOWER LEG




4PCS


HARDWARE IDENTIFICATION

1	PALSTIC (8mm)		1PC
2	L METAL (24 x 13 x 1.5mm)		2PCS
3	PLASTIC LINE (270mm)	\bigcirc	1PC
4	LARGE SCREW (8 x 25mm)	Фишшир	1PC
5	SMALL SCREW (8 x 15mm)	Фишт	1PC


STEP 1



STEP 2



STEP 3



FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture
This restraint not a substitute for proper adult supervision
This restraint may provide protection against tipping furniture.
Do not allow children to climb on furniture.
Failure to detach this restraint before moveing funiture may
rsult injury and damage

PAGE 2 OF 2

COASTERFURNITURE.COM

ITEM: **950059**ASSEMBLY INSTRUCTIONS



