

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

120452 *BAR TABLE*

REVISION 0: 08/25/2017 REVISION 1: 09/06/2022

PAGE 1 OF 10



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 55 MINUTES

PARTS IDENTIFICATION

A	TOP GLASS	1PC
В	SIDE BOARD	2PCS
С	TOP BOARD	1PC
D	BASE AND MIDDLE SHELF	3PCS
E	BOTTLE RACK	2PCS
F	DRAWER FRONT PANEL	2PCS
	PAGE 2 OF 10	COASTERFURNITURE.COM

DRAWER SIDE PANEL G 2PCS Н DRAWER BOTTOM PANEL 1PC TOP GLASS SUPPORT BAR 1PC **CENTER SUPPORT WOOD** J 1PC Κ **CENTER SUPPORT METAL** 1PC L **CENTER SWIVEL PART** 1PC TOP GLASS SUPPORT LEG 1PC М

PAGE 3 OF 10

N GLASS HOLDER




2PCS

HARDWARE IDENTIFICATION


CAM-BOLT (38mm)	(T.) M	20PCS	9 LARGE ALLEN KEY (5mm)	1PC			
LARGE CAM-LOCK (ø15mm)		16PCS	10 SCREW (7# x 5/8")	14PCS			
LARGE ALLEN BOLT (5/16" x 2-1/2" SR)		2PCS	11 FLOOR PROTECTOR (\$\phi\$ 30mm)	4PCS			
PLASTIC WASHER (5/16" x 50mm)		1PC	12 GLUE	1PC			
SMALL CAM-BACK (ø15 x 9.5mm)	9	4PCS	13 SMALL ALLEN BOLT (1/4" x 12mm SR)	6PCS			
SMALL WASHER (5/16" SR)	0	2PCS	14 LARGE WASHER (5/16" x 50mm)	2PCS			
SPRING WASHER (5/16" SR)		2PCS	15 LABEL	4PCS			
WOOD DOWEL (8 x 30mm)		20PCS	16 SMALL ALLEN KEY (4mm)	1PC			
	(38mm) LARGE CAM-LOCK (Ø15mm) LARGE ALLEN BOLT (5/16" x 2-1/2" SR) PLASTIC WASHER (5/16" x 50mm) SMALL CAM-BACK (Ø15 x 9.5mm) SMALL WASHER (5/16" SR) SPRING WASHER (5/16" SR)	(38mm) LARGE CAM-LOCK (\$\phi\15\text{mm}\$) LARGE ALLEN BOLT (5/16" x 2-1/2" SR) PLASTIC WASHER (5/16" x 50mm) SMALL CAM-BACK (\$\phi\15 x 9.5\text{mm}\$) SMALL WASHER (5/16" SR) SPRING WASHER (5/16" SR)	(38mm) LARGE CAM-LOCK (\$\psi\$15mm) LARGE ALLEN BOLT (5/16" x 2-1/2" SR) PLASTIC WASHER (5/16" x 50mm) SMALL CAM-BACK (\$\psi\$15 x 9.5mm) SMALL WASHER (5/16" SR) SPRING WASHER (5/16" SR) PLOS 2PCS 2PCS 2PCS 2PCS	Common C			



STEP 1




STEP 2




PAGE 5 OF 10



STEP 3




STEP 4






STEP 5




STEP 6






STEP 7




STEP 8




PAGE 8 OF 10




STEP 9



STEP 10 COMPLETE





COASTERFURNITURE.COM

PAGE 9 OF 10



