

## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



PAGE 1 OF 3

COASTERFURNITURE.COM

## ITEM: 224492 ASSEMBLY INSTRUCTIONS



- ASSEMBLY TIPS:
- 1. Remove hardware from box and sort by size.

WARNING!

- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

## $\triangle$

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.





A NIGHTSTAND

.

B LEG

4PCS

1PC

HARDWARE IDENTIFICATION

1	BOLT (Φ5/16" x 20mm - RBW)		12PCS
2	LOCK WASHER (Ф5/16" - RBW)		12PCS
3	FLAT WASHER (Ф5/16" - RBW)		12PCS
4	ALLEN WRENCH (4mm x 59mm - RBW)		1PC
		PAGE 2 OF 3	COASTERFURNITURE.COM

## ITEM: 224492 ASSEMBLY INSTRUCTIONS STEP 1





