


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life





COASTERFURNITURE.COM

ITEM: 107593 ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.





PARTS IDENTIFICATION



ITEM: 107593 ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.


HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 - BLK)		1PC
2	SHORT BOLT (M6 x 35mm - BK)		12PCS
3	MEDIUM BOLT (M6 x 50mm - BK)		4PCS
4	LONG BOLT (M6 x 60mm - BK)		4PCS
5	HALF ROUND NUT (M6 - BLK)	Ø	4PCS
6	LOCK WASHER (M6 - BK)	0	16PCS
7	FLAT WASHER (M6 - BK)	\bigcirc	12PCS
8	PLASTIC DOWEL (M8 x 30mm - BLK)		14PCS
9	FLAT HEAD SCREW (M4 x 38mm - RBW)	D	2PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


PAGE 3 OF 5



ITEM: 107593


ASSEMBLY INSTRUCTIONS STEP 5







*** Do not fully tighten the bolt





*** Please fully tighten all the bolts





COASTERFURNITURE.COM