

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

180019 Counter Height Stool

REVISION 0: 05/27/2005 REVISION 1: 11/22/2012 REVISION 2: 09/26/2018 REVISION 3: 08/02/2019

ITEM: 180019

COASTER

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

AV	LEG FRAME	2PCS
в۷	WOODEN SEAT	1PC
CV	STRETCHER	2PCS

HARDWARE IDENTIFICATION

1	HEX HEAD SCREW (Φ1/4" x 30mm - GD)	8PCS
2	ALLEN WRENCH (4MM - GD)	1PC
3	WOOD PLUG (Φ13mm - SR)	8PCS


NOTE:

Quantities shown are for one stool.


ITEM: 180019

ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2



STEP 3



STEP 4



STEP 5 COMPLETE






PAGE 3 OF 3

COASTERFURNITURE.COM

ITEM: 180019





Note: Dimension tolerance ±5%

COASTERFURNITURE.COM