

## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

180029 Bar Stool

REVISION 0 : 05/27/2005 REVISION 1 : 11/22/2012 REVISION 2 : 09/10/2015 REVISION 3 : 09/26/2018 REVISION 4 : 08/02/2019

PAGE 1 OF 3

COASTERFURNITURE.COM

#### ITEM: 180029

# COASTER

#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

#### **PARTS IDENTIFICATION**

AV	LEG FRAME	2PCS
в۷	WOODEN SEAT	1PC
cv	STRETCHER	2PCS

### **HARDWARE IDENTIFICATION**

1	HEX HEAD SCREW (Φ1/4" x 30mm - GD)	8PCS
2	ALLEN WRENCH (4MM - GD)	1PC
3	WOOD PLUG (Φ13mm - SR)	8PCS

#### NOTE:


Quantities shown are for one stool.

## ITEM:180029


# COASTER

#### **ASSEMBLY INSTRUCTIONS**


### STEP 1




### STEP 2



STEP 3



STEP 4



STEP 5 COMPLETE






PAGE 3 OF 3

COASTERFURNITURE.COM

ITEM: 180029





Note: Dimension tolerance ±5%