

***ASSEMBLY INSTRUCTIONS***  
***COASTER FINE FURNITURE***



*Fine Furniture for every stage of life*

**511161**

**SOFA**

# ITEM:511161



## ASSEMBLY INSTRUCTIONS


### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!







1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.







ASSEMBLY TIME

3 MINUTES


## PARTS IDENTIFICATION

A	BASE		1PC	B	LEFT EAR		1PC
C	BACKREST		1PC	D	RIGHT EAR		1PC
E	LEG		4PCS	F	SUPPORT LEG		1PC


## HAREWARE IDENTIFICATION

1	WASHER	 Ø0.6CM	8 PCS	3	BOLT	 6*30MM	8 PCS
2	WRENCH	 Ø0.6CM	1 PC	4	TRIPLE HEAD SCREW	 8*58MM	1 PC


# STEP 1




# STEP 2



# STEP 3





Note: Dimension tolerance  $\pm$  5%