

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

511088 Sectional

PAGE 1 OF 6


COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.

2. Please check to see that all hardawre and parts are present prior to start of assembly.



WA 1.Do

1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately. 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 3 MINUTES PARTS IDENTIFICATION

B1(BOX1)






B SOFA ARM BASE

COASTER®

C SOFA BACK CUSHION



D SOFA LEG



1PC

E SOFA BACK BASE



1PC

B2(BOX2)

F CHAISE BASE



1PC **G** CHAISE ARM



1PC

H CHAISE LEG



6PCS

I CHAISE BACK CUSHION



J CHAISE CLIP



2PCS


PAGE 2 OF 6

COASTERFURNITURE.COM


ASSEMBLY INSTRUCTIONS

STEP 1






STEP 2




ASSEMBLY INSTRUCTIONS

STEP 3





STEP 4





PAGE 4 OF 6

COASTERFURNITURE.COM


CONTROLLER INSTRUCTIONS











Note: Dimension tolerance ± 5%