


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

300186QF Queen / Full Headboard

REVISION 0: 21/12/2011 REVISION 1: 03/08/2023

PAGE 01 OF 04

COASTERFURNITURE.COM

ITEM: 300186QF

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

15 MINUTE

PARTS IDENTIFICATION



HARDWARE IDENTIFICATION

1	BOLT (1/4"x2-1/4" - BLK)		4PCS	5	NUT (ø1/4"x11x8mm - BLK)		8PCS
2	BOLT (1/4"x7/8" - BLK)		4PCS	6	PLASTIC END CAP (Ø1-1/2"mm - BLK)		2PCS
3	WASHER (¢16mm - BLK)	0	12PCS	7	ALLEN KEY (4x22X60mm - BLK)		1PC
4	WASHER (¢25mm - BLK)		8PCS	8	WRENCH (11.3x12.5X55mm - WHT)	\sum	1PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:300186QF

COASTER


ASSEMBLY INSTRUCTIONS

STEP 1:

ASSEMBLY


Do not fully tighten all bolts until assembly is complete. This will help all parts to assemble properly.

60" ASSEMBLY INSTRUCTIONS



STEP 2:


54" ASSEMBLY INSTRUCTIONS



ITEM:300186QF


ASSEMBLY INSTRUCTIONS

STEP 3:



ITEM:300186QF





Note: Dimension tolerance ±5%