


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

COFFEE TABLE

753278

ITEM: 753278

ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLE TIME

10 MINUTES

PARTS IDENTIFICATION

B1: TOP

A _____

MIRROR CABINET

1PC

c 🗇 🖹

BASE

1PC

B2: LEG




LEG

2PCS

HARDWARE


1		BOLT 8x35MM	16PCS
2	0	WASHER Φ20x2MM	16PCS
3		ALLEN KEY 30x80MM	1PC

HARDWARE PACK IS LOCATED IN 753278 (B1)



ITEM: 753278





Note: Dimension tolerance ±5%