

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

511087 Sectional

REVISION 0:07/17/2023 REVISION 0:08/16/2023

PAGE 1 OF 6


COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.

2. Please check to see that all hardawre and parts are present prior to start of assembly.



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately. 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 3 MINUTES PARTS IDENTIFICATION

1(BOX1)




B SOFA ARM BASE 1PC

COASTER[®]

C SOFA BACK CUSHION



D SOFA LEG



SOFA BACK BASE



1 PC

B2(BOX2)

CHAISE BASE



1PCG CHAISE ARM



CHAISE LEG



6PCS

T CHAISE BACK CUSHION



CHAISE CLIP




2PCS

PAGE 2 OF 6


COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS **STEP 1**






STEP 2




ASSEMBLY INSTRUCTIONS

STEP 3





STEP 4





PAGE 4 OF 6

COASTERFURNITURE.COM


CONTROLLER INSTRUCTIONS














Note: Dimension tolerance ± 5%