


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

950179 CURIO CABINET

REVISION 0: 03/15/2018 REVISION 1: 06/19/2023

PAGE 1 OF 9



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.





PARTS IDENTIFICATION

А	DOOR GLASS 790x381mm		1PC
В	SIDE GLASS 810x345mm		2PCS
С	BACK GLASS 810x386mm		1PC
D	PLASTIC BAR		2PCS
E	INNER SHELF SUPPORT		2PCS
F	TOP WOOD PANEL		1PC
G	BOTTOM WOOD PANEL		1PC
		_	

ITEM: 950179 ASSEMBLY INSTRUCTIONS PARTS IDENTIFICATION



H GLASS SHELF 382x250mm




2PCS

HARDWARE IDENTIFICATION


1	PLASTIC FEET (ø 44 x 18mm)		4PCS	9	HANDLE (40mm)		1PC
2	BOLT-LARGE (1/4" x 1-3/4")	0)	8PCS	10	METAL CONTACT (40mm)		1PC
3	WASHER (1/4" x 16mm)	0	8PCS	11	TWIN ADHESIVE (38 x 42mm)	\Diamond	2PCS
4	HINGE (40mm)	The state of the s	2PCS	12	SCREW (Ø8 x 22mm)	E primer	4PCS
5	HINGE INSERT (ø12 x 9mm)		2PCS	13	SUCTION CUP (ø12mm)		8PCS
6	METAL CONTACT (38mm)		2PCS	14	ALLEN KEY (4mm)		1PC
7	BOLT-SMALL (ø7 x 6mm)		4PCS	15	STICKER (ø20mm)	0	4PCS
8	PLASTIC MAGNET (19mm)		2PCS				
				•			



STEP 1




STEP 2




PAGE 4 OF 9



STEP 3




STEP 4




PAGE 5 OF 9




STEP 5





STEP 6




LEFT

PAGE 6 OF 9





STEP 6



RIGHT

STEP 7 COMPLETE






PAGE 7 OF 9





Product Size: 427 X 362 X 855 H (MM)

Product Size : $16\frac{3}{4}$ " X $14\frac{1}{4}$ " X $33\frac{1}{2}$ "



ITEM: 950179



ANTI-TIPPING INSTALLMENT INSTRUCTIONS FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.

This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.


This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

This tip restraint must be attached to a wall stud using long screw enclosed.


STEP 1

Attach a bracket securely to the back top rail of the furniture using short screw provided, through the smaller hole.



STEP 2

Locate the other bracket on the wall over a plastic wall stud and two inches below the mounting bracket secured to the back of the furniture. Attach the wall stud using the long screw provided, through the smaller hole.



STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end and draw it through until all slack is removed. Confirm that the strap is securely laced and locked.

