

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

205897STL *Stool* 

## ITEM: 205897STL

#### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

#### **PARTS IDENTIFICATION**

A SEAT 1PC

B LEG 4PCS

#### HARDWARE IDENTIFICATION


1	ALLEN WRENCH (M4 x 60MM - BLK)	1PC
2	BOLT (M6 x 50mm - BLK)	8PCS
3	LOCK WASHER (1/4" - BLK)	8PCS
4	FLAT WASHER (1/4" X 19mm - BLK)	8PCS

## ITEM: 205897STL




#### **ASSEMBLY INSTRUCTIONS**

#### STEP 1




### STEP 2 COMPLETE





# ITEM: 205897STL





Note: Dimension tolerance ± 5%