


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

800309 BOOKCASE

REVISION 0: 01/22/2018 REVISION 1: 07/12/2022

PAGE 1 OF 8

COASTERFURNITURE.COM

ITEM:800309 ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 90 MINUTES

PARTS IDENTIFICATION

A	TOP PANEL			1PC
В	LEFT SHELF			1PC
С	BOTTOM LEFT SHELF			1PC
D	RIGHT SHELF			1PC
E	CENTER SHELF			1PC
		PAGE 2 OF 8	COASTERFU	JRNITURE.COM

ITEM:800309 ASSEMBLY INSTRUCTIONS PARTS IDENTIFICATION



F	BOTTOM PANEL	1PC
G	LARGE SIDE PANEL	3PCS
Н	SMALL SIDE PANEL	1PC
I	MEDIUM SHELF	5PCS
J	SHELF	5PCS
К	CROSSBAR	3PCS

ITEM:800309

ASSEMBLY INSTRUCTIONS



HARDWARE IDENTIFICATION

1	THREADED ROD (1/4" x 63mm)		3PCS
2	WOOD DOWEL (8 x 35mm)		48PCS
3	LONG BOLT (1/4" x 63mm)		3PCS
4	STICKER (ø20mm)	0	8PCS
5	LARGE BOLT (7# x 70 mm)		16PCS
6	GLUE		1PC
7	CAP (30 x 30mm BLK)		6PCS
8	FLOOR PROTECTOR (15 x 12mm)		5PCS
9	ALLEN WRENCH (4mm)		1PC
1			


ITEM:800309


ASSEMBLY INSTRUCTIONS



STEP 1

Do not tighten until each step is completed or instructed.







ITEM:800309 ASSEMBLY INSTRUCTIONS



STEP 3



STEP 4




ITEM:800309 ASSEMBLY INSTRUCTIONS



Product Size : 1200 X 290 X 1610 H (MM)

Product Size : 47 ¼" X 11 ½" X 63 ¼"



Note: Dimension tolerance ±5%

ITEM: 800309



ANTI-TIPPING INSTALLMENT INSTRUCTIONS FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.

This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.


This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

This tip restraint must be attached to a wall stud using long screw enclosed.


STEP 1

Attach a bracket securely to the back top rail of the furniture using short screw provided, through the smaller hole.



STEP 2

Locate the other bracket on the wall over a plastic wall stud and two inches below the mounting bracket secured to the back of the furniture. Attach the wall stud using the long screw provided, through the smaller hole.



STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end and draw it through until all slack is removed. Confirm that the strap is securely laced and locked.

