

## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

**400730T**  
**Bunkbed T/T**

# ITEM: 400730T



## ASSEMBLY INSTRUCTIONS


### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

50 MINUTES

## PARTS IDENTIFICATION

A1 LEG 1		2PCS	B1 LEG 2		2PCS
C1 LEG 3		2PCS	D1 LEG 4		2PCS
E1 CONNECTING ROD		4PCS	F1 HEADBOARD 1		2PCS
G1 HEADBOARD 2		2PCS	H1 RAIL 1		1PC
I1-RAIL 2		1PC	J1 RAIL 3		2PCS
K1 LADDER RISER		2PCS	L1 LADDER TRANSVERSE TUBE		4PCS
M1 SLAT		44PCS	N1 GUARDRAIL 1		1PC
O1 GUARDRAIL 2		1PC	P1 SLAT CONNECTOR		88PCS
Q1 SLAT SPACER		21PCS			

## HARDWARE IDENTIFICATION

### Z - HARDWARE

1	BOLT (Ø 1/4"x20 MM)		40PCS	4	BOLT (Ø 1/4"x 65MM)		9PCS
2	BOLT (Ø 1/4"x35 MM)		11PCS	5	ALLEN WRENCH(1/4")		2PCS
3	BOLT (Ø 1/4")		3PCS				




ITEM: **400730T**


## ASSEMBLY INSTRUCTIONS




### STEP 1




### STEP 2



### STEP 3




### STEP 4




ITEM: **400730T**  
**ASSEMBLY INSTRUCTIONS**




**STEP 5**




**STEP 6**



**STEP 7**



**STEP 8**




ITEM: **400730T**


## ASSEMBLY INSTRUCTIONS




### STEP 9





### STEP 10



### STEP 11



### END






ITEM: **400730T**


## ASSEMBLY INSTRUCTIONS



### DIMENSIONAL DRAWING



Note : Dimension tolerance  $\pm 5\%$



ITEM: **400730T**

## ASSEMBLY INSTRUCTIONS



### SIZE OF MATTRESS

The length and width of the bunk mattress are as follow:

	<u>Length</u>	<u>Width</u>	<u>Thickness</u>
Upper bunk	74" - 75"	37 1/2" - 38 1/2"	6" Maximum
Lower bunk	74" - 75"	37 1/2" - 38 1/2"	6" Maximum

*Ensure thickness of mattress does not exceed 6" and there must be at least 5" from mattress sleeping surface to top edge of guardrail.*



## SAFETY WARNING



1. Follow the information on the warnings appearing on the upper bunk end structure and on the carton. Do not remove the warning label from bed.
2. Always use the recommended size mattress or mattress support or both to help prevent the likelihood of entrapment or falls.
3. Surface of mattress must be at least 5 in. (127mm) below the upper edge of guardrails.
4. Do not allow children under 6 years of age to use the upper bunk.
5. Prohibit more than one person on upper bunk.
6. Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
7. Do not allow horseplay on or under the bed and prohibit jumping on the bed.
8. Always use the ladder for entering and leaving the upper bunk.
9. Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.
10. Use of a night light may provide added safety precaution for a child using upper bunk.
11. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
12. The use of water or sleep flotation mattress is prohibited.
13. Keep these instructions for future reference.

### STRANGULATION HAZARD:

14. Never attach or hang items to any part of the bed that are not designed for use with the bed for example, but not limited to hooks, belts, and jump ropes.

### REPLACEMENT PARTS:

Replacement parts, including additional guardrails may be obtained from any COASTER Furniture Dealer.



ITEM: **400730T**

## ASSEMBLY INSTRUCTIONS



# **WARNING**

## TO PREVENT SERIOUS OR FATAL INJURY

1. When using beds as bunk beds, the ladder **MUST** be securely attached to the upper bunk rail at all times.
2. When using the beds as two (2) separate floor-standing beds, the ladder **MUST** be stored in a separate location where children cannot use the ladder in any manner.
3. **DO NOT** use, nor permit children to use, the ladder in any manner whatsoever, other than to access the top unit when used as bunk beds, and only if the ladder is securely attached to the top bunk rail, as set forth in the instructions.
4. Any misuse or unauthorized use of the ladder could result in serious or fatal injury.
5. Failure to follow the above warning , or failure to follow the assembly instructions completely, will void all liability of COASTER COMPANY OF AMERICA for damages and injury to people and property.



**Coasterfurniture.com | 877-COASTER (262-7837)**