

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

300321 Sofa Bed

REVISION 0: 05/03/2019 REVISION 1: 03/16/2021 REVISION 2: 07/21/2022 REVISION 3: 08/11/2023 REVISION 4: 10/20/2023 **ITEM: 300321**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- Please check to see that all hardware and parts are present prior to start of assembly.
 Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

SOFA BED



1PC

LEGS





4PCS

HARDWARE IDENTIFICATION

Z 01	SCREW (4 x 25mm - BLK)	∠ (X)	16PCS	Z03	WASHER (8 x 19mm - BLK)	8PCS
Z02	BOLT (6 x 30mm - BLK)		8PCS	Z 04	WRENCH (D 4mm - BLK)	1PC

STEP 1





ITEM: 300321

COASTER® FINE FURNITURE

ASSEMBLY INSTRUCTIONS

PRODUCT DIMENSION (Note: Dimension tolerance ±5%)

