

## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 10/25/2023

COASTERFURNITURE.COM

PAGE 1 OF 4

# ITEM: 300838

### **ASSEMBLY INSTRUCTIONS**




### ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

# MARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



## HARDWARE IDENTIFICATION

1	BOLT (Φ1/4x 100MM - WHT)		4PCS
2	HEX HEAD SCREW (Ф5/16x 80MM- WHT)	<u>()</u> >	4PCS
3	FLAT HEAD SCREW (Ф4 x 35MM - WHT)	(†)	10PCS
4	ALLEN WRENCH (Ф4 x 78MM - WHT)		1PC

#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



## ITEM: 300838 ASSEMBLY INSTRUCTIONS



## STEP 1

