

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

### 100424 LEISURE CHAIR

REVISION 0 : 11/01/2018 REVISION 1 : 05/13/2019 REVISION 2 : 09/15/2020 REVISION 3 : 08/01/2022 REVISION 4 : 16/11/2023

PAGE 1 OF 3

**COASTERFURNITURE.COM** 

## ITEM: 100424 ASSEMBLY INSTRUCTIONS



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.





ASSEMBLY TIME 5 MINUTES

#### **PARTS IDENTIFICATION**

Α		CHAIR SEAT	1PC
В		FOOT REST	1PC
С		GAS CYLINDER	1PC
D		CHAIR BASE	1PC
E		DECORATIVE RING	1PC
Z	HARDWARE IDENTIFICATION		
1		BOLT (M6x20mm)	4PCS
2		ALLEN WRENCH (M5)	1PC

Note:


Quantities shown are for one chair

#### ITEM: 100424


#### **ASSEMBLY INSTRUCTIONS**








STEP 2




Place the chair seat (A) upside down on a soft surface. Then attach the foot rest (B) to the chair seat (A) using the bolt (1) and tighten with the allen wrench (2).

#### STEP 3



STEP 4




PAGE 3 OF 3

AS SHOWN IN THE DRAWING.

**COASTERFURNITURE.COM** 

# ITEM: 100424 ASSEMBLY INSTRUCTIONS





Noted: Dimension tolerance ±5%