

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 05/09/2023

PAGE 1 OF 5

ITEM: 104172 ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.







PARTS IDENTIFICATION

A	BACK FRAME	1PC
В	SEAT FRAME	1PC
С	SEAT CUSHION	1PC
D	FRONT LEG	2PCS

NOTE:

Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

PAGE 2 OF 5

ITEM: 104172 ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 - BLK)		1PC
2	SHORT BOLT (M6 x 40mm - RBW)		2PCS
3	LONG BOLT (M6 x 70mm - RBW)		8PCS
4	LOCK WASHER (M6 - RBW)	Ö	10PCS
5	FLAT WASHER (M6 - RBW)	\bigcirc	10PCS
6	FLAT HEAD SCREW (M4 x 25mm- RBW)	Dimension	5PCS

NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

PAGE 3 OF 5

ITEM: 104172


ASSEMBLY INSTRUCTIONS STEP 1



ITEM: **104172**



ASSEMBLY INSTRUCTIONS STEP 3





PAGE 5 OF 5

