

### ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 01/30/2024

PAGE 1 OF 7

COASTERFURNITURE.COM

### ITEM:721618 ASSEMBLY INSTRUCTIONS



#### ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.


2. This product is for home use only and not intended for commercial establishments.



15 MINUTES

### PARTS IDENTIFICATION





### ITEM:721618 ASSEMBLY INSTRUCTIONS





Z	Z HARDWARE IDENTIFICATION			
1	BOLT ( 1/4" x 38mm - BLK )		4 PCS	
2	BOLT ( 1/4" x 44mm - BLK )		8 PCS	
3	SCREW ( Ø8 x 36mm - BLK )		4 PCS	
4	CAP (Ø25 x 15mm - BLK)		4 PCS	
5	CAP (Ø25 x 15mm - BLK)		4 PCS	
6	SUCTION CUP (Ø20 x 11mm)		4 PCS	
7	ALLEN WRENCH ( 4 x 57mm - SR )		1 PC	
Hardware pack is located in 721618B2				
		PAGE 3 OF 7	COASTERFURNITURE.COM	

# ITEM:721618

# COASTER<sup>®</sup>

#### ASSEMBLY INSTRUCTIONS STEP 1





## ITEM:721618



#### ASSEMBLY INSTRUCTIONS STEP 5

