

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

551300AC ARMLESS CHAIR

REVISION 0:11/03/2023 REVISION 1:12/12/2023

PAGE 1 OF 4

COASTERFURNITURE.COM


ITEM:551300AC

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately. 2. This product is for home use only and not intended for commercial establishments.





ASSEMBLY TIME

3 MINUTES

PARTS IDENTIFICATION

A ARMLESS CHAIR




1PC B LEG





4PCS


STEP 1




STEP 2








Note: Dimension tolerance ± 5%





Note: Dimension tolerance ± 5%