

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

610193P Power Recliner

## ITEM: 610193P

### **ASSEMBLY INSTRUCTIONS**



### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

# **PARTS IDENTIFICATION**

Α	SEAT	1PC
В	ВАСК	1PC
С	LEFT EAR	1PC
D	RIGHT EAR	1PC
E	ADAPTER	1PC
F	POWER CABLE	1PC

#### NOTE:


Phillips head screw driver is required in the assembly process; However, manufacturer not provide this item.

# ITEM: **610193P**


## **ASSEMBLY INSTRUCTIONS**

# COASTER


## STEP 1



## STEP 2




# STEP 3 COMPLETE





ITEM: **610193P** 





Note: Dimension tolerance± 5%