

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



223033 Dresser

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instruction in the same sequence as numbered to assure fast and easy assembly.



WARNING

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A DRESSER



1 PC

B LEG



4 PCS

C CENTER SUPPORT LEG WITH LEVELER



1 PC

HARDWARE IDENTIFICATION

1 THREADED BOLT (3/8" x 2 3/4" - SR)




4 PCS

ASSEMBLY INSTRUCTIONS







STEP 2 COMPLETE









ANTI-TIPPING INSTALLMENT INSTRUCTION FURNITURE TIPING RESTRAINT

WARNING

Injury may result from tipping furniture.

This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.


This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and demage.

This tip restraint must be attached to a wall stud using long screw enclosed.


STEP 1

Attach a bracket securely to the back top rail of the furniture using short screw provided, through the smaller hole.




STEP 2

Locate the other bracket on the wall over a wall stud and two inches below the mounting bracket secured to the back of the furniture. Attach the wall stud using the long screw provided, through the smaller hole.



STEP 3


Place the furniture into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end and draw it through until all slack is removed. Confirm that the strap is securely laced and locked.







Inner Size of Drawer A: 18.50"W X 13.00"D X 9.00"H X 0.50"T Inner Size of Drawer B: 18.50"W X 13.00"D X 3.75"H X 0.50"T Inner Size of Drawer C: 28.75"W X 13.00"D X 9.00"H X 0.50"T



Note: Dimension tolerance ± 5 %



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

223034 Mirror

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instruction in the same sequence as numbered to assure fast and easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A MIRROR

DRESSER
*FROM BOX ITEM # 223033

C MIRROR SUPPORT
(PACKED WITH MIRROR)

1 PC

2 PCS


HARDWARE IDENTIFICATION

1	BOLT (M6 x 40mm - BLK)	8 PCS
2	LOCK WASHER (M6 - BLK)	8 PCS
3	FLAT WASHER (M6 - BLK)	8 PCS
4	ALLEN WRENCH (M4 - BLK)	1 PC


ASSEMBLY INSTRUCTIONS

STEP 1





STEP 2 COMPLETE





ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instruction in the same sequence as numbered to assure fast and easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A MIRROR



1 PC

D LONG HANGING BAR (3mm X 32mm X 540mm - BLK)



2 PCS

HARDWARE IDENTIFICATION

5 PAN HEAD SCREW (8 x 2" - SR)




6 PCS


6 PLASTIC ANCHOR



6 PCS







Note: Dimension tolerance ± 5 %