

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

120715 *BAR TABLE*

REVISION 0: 09/04/2017 REVISION 1: 09/06/2022

PAGE 1 OF 6

COASTERFURNITURE.COM




ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME 45 MINUTES

PARTS IDENTIFICATION

Α	TOP GLASS		1PC
В	BASE	0	1PC
С	BOTTOM SHELF	e	1PC
D	TOP SHELF		1PC
Е	STEEL GUARD		1PC
F	TOP POST	Se established to the second t	1PC



G BOTTOM POST



1PC


HARDWARE IDENTIFICATION

1	LARGE ALLEN KEY (5/16" x 50mm SR)	D anggaran	1PC
2	SPRING WASHER (5/16")	©	1PC
3	HEXAGONAL (1/4")	B	1PC
4	NUT (1/4")		2PCS
5	MEDIUM ALLEN BOLT (1/4" x 63mm SR)	O mmanan	2PCS
6	SMALL ALLEN BOLT (1/4" x 12mm SR)	O mm	3PCS
7	WASHER (5/16" x 57mm)		1PC
8	ALLEN WRENCH (4mm,5mm)		1PC




STEP 1

Do not tighten until each step is completed or instructed.



STEP 2




PAGE 4 OF 6


COASTERFURNITURE.COM



STEP 3



STEP 4 COMPLETE








Product Size: 597 DIA X 1117H (MM)

Product Size: 23.5" DIA X 44"



Note: Dimension tolerance ±5%