

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

506593 CHAIR

REVISION 1: 05/12/2017 REVISION 2: 05/08/2019 REVISION 3: 05/16/2023 REVISION 4: 10/13/2023

COASTERFURNITURE.COM

ITEM: 506593

ASSEMBLY INSTRUCTIONS

COASTER® FINE FURNITURE


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 15 MINUTES

PARTS IDENTIFICATION


A



BASE

1PC

В



BACK

1PC

C




LEG

4PCS


Z HARDWARE PACKAGE

NO	DESCRIPTION	FIGURE	Q'TY
(1)	SCREW φ5MM*50MM	Danner-	12PCS



ITEM: 506593





Note: Dimension tolerance ±5%

COASTERFURNITURE.COM