

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

931143 *VANITY*

REVISION 0: 01/28/2021 REVISION 1: 05/24/2022 REVISION 2: 03/18/2024

PAGE 1 OF 24




ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 99 MINUTES

B2: VANITY BASE & GLASS PARTS IDENTIFICATION

TOP PANEL 1PC В LEFT CABINET LEFT PANEL 1PC C LEFT CABINET RIGHT PANEL 1PC D RIGHT CABINET LEFT PANEL 1PC **PAGE 2 OF 24** COASTERFURNITURE.COM

ITEM:931143 ASSEMBLY INSTRUCTIONS PARTS IDENTIFICATION E RIGHT CABINET RIGHT PANEL

F BACK PANEL 2PCS

G SUPPORT PANEL 2PCS

H BOTTOM PANEL 2PCS

I MIDDLE BOTTOM PANEL 1PC

PAGE 3 OF 24

COASTERFURNITURE.COM


1PC



	<u>.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,</u>	<u></u>	
J	MIDDLE BACK PANEL	1PC	
К	LONG TOP SUPPORT PANEL	1PC	
L	SHORT TOP SUPPORT PANEL	2PCS	
М	DOOR PANEL	. 1PC	
N	LARGE DRAWER FRONT PANEL	1PC	
	PAGE 4 OF 2	COASTERFURNITURE.	COM




O LARGE AND SMALL DRAWER LEFT PANEL




3PCS

P LARGE AND SMALL DRAWER RIGHT PANEL




3PCS

Q LARGE DRAWER BACK PANEL



1PC

R LARGE DRAWER BOTTOM PANEL



1PC

S SMALL DRAWER FRONT PANEL



2PCS



T SMALL DRAWER BACK PANEL



2PCS

U MEDIUM AND SMALL DRAWER BOTTOM PANEL




6PCS

V MEDIUM DRAWER FRONT PANEL



4PCS

A1 MEDIUM DRAWER LEFT PANEL



4PCS

A2 MEDIUM DRAWER RIGHT PANEL




4PCS



A3 MEDIUM DRAWER BACK PANEL

4PCS

A4 SHELF PANEL



A5 RIGHT CABINET SUPPORT PANEL




2PCS

A6 HINGE



2PCS

A7 GLASS



PAGE 7 OF 24




A8 HANDLE



8PCS

B1: VANITY TOP

A9 CROSSBAR



2PCS

A10 MAKE-UP MIRROR



1PC

B3: 11PCS LIGHT BULB

A11 LIGHT BULB

TYPE G / E26 CLEAR LIGHT BULB / 4 WATT.



11PCS



Z	HARDWARE IDENTIFICATION


1	LARGE CAM BOLT (35MM)	022	26PCS	11	SHELF BOLT	©	4PCS
2	SMALL CAM BOLT	67. Jan	18PCS	12	CAP (13 x 26mm)		4PCS
3	LARGE CAM-LOCK (ø15MM)		30PCS	13	SUCTION CUP		8PCS
4	SMALL CAM-LOCK (ø12mm)	9	14PCS	14	LONG BOLT (1/4" x 25mm SR)	0	12PCS
5	WOOD DOWEL (8 x 30mm)		50PCS	15	GLUE		1PC
6	WOOD DOWEL (6 x 25mm)		14PCS	16	ALLEN WRENCH (4mm)		1PC
7	LONG SCREW (8 x 25mm)	Opposition	28PCS	17	FOOT PIN		8PCS
8	SHORT SCREW (3.5 x 12mm)	& Thomas	12PCS				
9	SMALL BOLT (5/32" x10mm)	•	14PCS				
10	LONG BOLT (5/32" x22mm)		8PCS				

Hardware pack is located in 931143B2




STEP 1

Do not tighten until each step is completed or instructed.












STEP 3





COASTERFURNITURE.COM


STEP 4




PAGE 12 OF 24




STEP 5






STEP 6




PAGE 13 OF 24



STEP 7






PAGE 14 OF 24





STEP 8






STEP 9






STEP 10




PAGE 16 OF 24



15




STEP 12




PAGE 17 OF 24




STEP 13







STEP 14






STEP 15






<u>STEP 16</u>




ITEM:931143 ASSEMBLY INSTRUCTIONS STEP 17 5 **STEP 18** PAGE 20 OF 24 COASTERFURNITURE.COM



STEP 19




STEP 20




PAGE 21 OF 24



STEP 21





ITEM:931143 **ASSEMBLY INSTRUCTIONS** Product Size: 1181 X 470 X 1562 H (MM) Product Size : 46.5" X 18.5" X 61.5" 61.5" 0 0 5.67" Note: Dimension tolerance ±5% PAGE 23 OF 24 COASTERFURNITURE.COM

ITEM: 931143



ANTI-TIPPING INSTALLMENT INSTRUCTIONS FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.

This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.


This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

This tip restraint must be attached to a wall stud using long screw enclosed.


STEP 1

Attach a bracket securely to the back top rail of the furniture using short screw provided, through the smaller hole.



STEP 2

Locate the other bracket on the wall over a plastic wall stud and two inches below the mounting bracket secured to the back of the furniture. Attach the wall stud using the long screw provided, through the smaller hole.



STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end and draw it through until all slack is removed. Confirm that the strap is securely laced and locked.

