

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

360045 Sofa Bed

**REVISION 0: 03/21/2024** 

**PAGE 1 OF 3** 

**COASTERFURNITURE.COM** 

### ITEM: 360045



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

## $\mathbb{N}$

#### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

**30 MINUTES** 

#### PARTS IDENTIFICATION


A SOFA BED 1PC C BACK LEG 2 PCS

B FRONT LEG 2PCS

#### **Z HARDWARE IDENTIFICATION**

**Z**01 **BOLT** 4PCS **Z03** ALLEN WRENCH 🥒 1PC (8 x 30mm - BLK) (D 5mm - BLK) **PLASTIC WASHER** 2PCS **Z02** WASHER 4PCS **Z04** (D 50mm - BLK) (10 x 25mm - BLK)

### STEP 1



## **ITEM: 360045**

# COASTER® FINE FURNITURE

#### **ASSEMBLY INSTRUCTIONS**

PRODUCT DIMENSION (Note: Dimension tolerance ±5%)

