

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

181025 SERVING CART

REVISION 0: 09/08/2023 REVISION 1: 04/18/2024

PAGE 1 OF 14



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 65 MINUTES

PARTS IDENTIFICATION

A	TOP TRAY		: : : : 1PC
В	BOTTOM TRAY		1PC
С	LEFT PANEL		1PC
D	RIGHT PANEL	6	1PC
E	BACK PANEL		1PC
		PAGE 2 OF 13	COASTERFURNITURE.COM

ITEM:181025 ASSEMBLY INSTRUCTIONS PARTS IDENTIFICATION



COASTERFURNITURE.COM


		<u> </u>
F	DRAWER FRONT PANEL	1PC
G	DRAWER LEFT PANEL	1PC
Н	DRAWER RIGHT PANEL	1PC
I	DRAWER BACK PANEL	1PC
J	DRAWER BOTTOM PANEL	1PC
К	LEG 1	2PCS

PAGE 3 OF 14


ITEM:181025 ASSEMBLY INSTRUCTIONS PARTS IDENTIFICATION




L LEG 2




M TOP CROSSBAR




N MIDDLE CROSSBAR




O BOTTOM CROSSBAR



P HANDLE



Q HOLDER



PAGE 4 OF 14



COASTERFURNITURE.COM

R	DRAWER HANDLE					\geqslant	1PC		
S	SLIDE RAIL				5:3	3	2PCS		
Т	WHEEL						4PCS		
Z	Z HARDWARE IDENTIFICATION								
1	CAM BOLT (38mm)	STA MIN	6PCS	9	LONG BOLT (1/4" x 21mm SR)		4PCS		
2	CAM LOCK (ø15mm)		6PCS	10	CAP (13 x 26mm SR)		8PCS		
3	WOOD DOWEL (8 x 30mm)		10PCS	11 [DRAWER HANDLE CAP (16 x 16mm SR)		2PCS		
4	WOOD SCREW (8 x 38mm)	® 2000000000000000000000000000000000000	4PCS	12	HANDLE CAP (20 x 20mm SR)		2PCS		
5	HANDLE BOLT (5/32" x 22mm)		2PCS	13	GLUE		1PC		
6	SMALL BOLT (5/32" x 12mm)		2PCS	14	HOLDER BOLT (3/16" x 12mm SR)		8PCS		
7	SCREW (3 x 8mm)	Bann	6PCS	15	ALLEN WRENCH (4mm)		1PC		
8	SHORT BOLT (1/4" x 12mm SR)	9	16PCS	16	HEXAGONAL KEY (8mm)	ß	1PC		


PAGE 5 OF 14




COASTERFURNITURE.COM

STEP 1

Do not tighten until each step is completed or instructed.




STEP 2




PAGE 6 OF 14

ASSEMBLY INSTRUCTIONS STEP 3 13 13 COASTER FINE FUNITURE


STEP 4









STEP 6








STEP 8




PAGE 9 OF 14



STEP 9




STEP 10




PAGE 10 OF 14



STEP 11




STEP 12






STEP 13



STEP 14




PAGE 12 OF 14






STEP 15



STEP 16 COMPLETE





PAGE 13 OF 14



Product Size: 826 X 400 X 889 H (MM)

Product Size: 32.5" X 15.75" X 35"





Note: Dimension tolerance ±5%