

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

224865 Chest

ITEM: 224865

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A CHEST

1PC

B LEG FRAME

2PCS

C UPPER CROSSBAR

2PCS

D LOWER CROSSBAR

HARDWARE IDENTIFICATION

1	LONG BOLT (M6 x 40mm - BLK)	6PCS
2	SHORT BOLT (M6 x 30mm - BLK)	2PCS
3	ALLEN WRENCH (M4 x 60mm - BLK)	1PC
4	PAN HEAD SCREW (M4 x 32mm - BLK)	6PCS

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:224865




ASSEMBLY INSTRUCTIONS


STEP 1



STEP 2



NOTE: DO NOT FULLY TIGHTEN IN THIS STEP.




ITEM:**224865**

COASTER

ASSEMBLY INSTRUCTIONS

STEP 4



NOTE: FULLY TIGHTEN IN THIS STEP.


STEP 5 COMPLETE







Inner Size of Drawer: 27.75"W x 11.25"D x 5.25"H x 0.25"T



Note: Dimension tolerance ± 5%