

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

181368 Counter Stool

REVISION 0: 09/26/2023

PAGE 1 OF 4

COASTERFURNITURE.COM

### **ASSEMBLY INSTRUCTIONS**



### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

### **PARTS IDENTIFICATION**

A	BACKREST	1PC
В	SWIVEL PLATE WITH FRAME	1PC
С	UPPER LEG	1PC
D	LOWER LEG	1PC
E	FOOTREST	1PC
F	SEAT CUSHION	1PC

### HARDWARE IDENTIFICATION

1	BOLT (M6 x45MM - BLK)	14PCS
2	LOCK WASHER (1/4" - BLK)	14PCS
3	FLAT WASHER (1/4"x 16MM - BLK)	10PCS
4	FLAT HEAD SCREW (M4 x 32MM - BLK)	4PC
5	ALLEN WRENCH (M4 x 65MM - BLK)	1PC

### NOTE:


Quantities shown are for one stool.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


## COASTER

## ASSEMBLY INSTRUCTIONS


### STEP 1



### STEP 2



### STEP 3




PAGE 3 OF 4

COASTERFURNITURE.COM


## COASTER

### **ASSEMBLY INSTRUCTIONS**

### STEP 4




# STEP 5 COMPLETE









Note: Dimension tolerance  $\pm 5\%$