

PAGE 1 OF 7

COASTERFURNITURE.COM

ITEM: 300718 (B1&B2)

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.



NOTE:

Phillips head screw driver is required in the assemply process; however, manufacturer does not provide this item.



ITEM: 300718 (B1&B2)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B2(BOX 2) - HARDWARE PACK IS LOCATED IN 300718(B2)

1	BOLT 1 (Ø5/16" x 20mm - RBW)		4PCS
2	BOLT 2 (Ø5/16" x 25mm - RBW)		8PCS
3	BOLT 3 (Ø5/16" x 38mm - RBW)		8PCS
4	BOLT 4 (Ø5/16" x 60mm - RBW)		4PCS
5	FLAT WASHER (Ø5/16" x 19mm - RBW)		24PCS
6	LOCK WASHER (Ø5/16'' x R6.5 - RBW)	\bigcirc	24PCS
7	ALLEN WRENCH (M5 x 75mm x 32mm)		1PC
8	METAL PLATE (100mm x 40mm x 2mm)	00	2PCS
9	FLAT HEAD SCREW (M4 x 30mm - RBW)	,,,,,,,,,,,,, ,	12PCS

NOTE:

Phillips head screw driver is required in the assemply process; however, manufacturer does not provide this item.



