

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



# 903095 ACCENT CHAIR

# ITEM:903095

#### ASSEMBLY INSTRUCTIONS



#### ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




#### WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



#### PARTS IDENTIFICATION: Z HARDWARE IDENTIFICATION




NO	DESCRIPTION	FIGURE	QTY
1	BOLT (M8 x 45mm)-SR		4 PCS
2	BOLT (M8 x 60mm)-SR		2 PCS
3	FLAT WASHER (M8)-SR	0	6 PCS
4	IRON SHEET		2 PCS
5	NUT		2 PCS
6	BOLT		2 PCS
7	OPEN END WRENCH	5	1 PC
8	ALLEN KEY (M6)-SR		1 PC

# $\mathsf{ITEM:}903095$


### **ASSEMBLY INSTRUCTIONS**







#### STEP 2





COASTERFURNITURE.COM

# ITEM:903095

### ASSEMBLY INSTRUCTIONS







## ITEM:903095

### ASSEMBLY INSTRUCTIONS

Note: Dimension tolerance  $\pm 5\%$ 



COASTERFURNITURE.COM

