



**ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE**



Fine Furniture for every stage of life

504854

OTTOMAN

ITEM : 504854



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A

OTTOMAN



1PC


B

LEG




4PCS


ITEM : 504854
ASSEMBLY INSTRUCTIONS
STEP 1




STEP 2



STEP 3



ITEM : 504854



NOTE: Dimension tolerance $\pm 5\%$

