

**ASSEMBLY INSTRUCTIONS**  
**COASTER FINE FURNITURE**



*Fine Furniture for every stage of life*

**509671**  
**SOFA**

# ITEM: 509671

## ASSEMBLY INSTRUCTIONS




### ASSEMBLY TIPS:

1. Remove plastic legs from sofa bottom and sort by size.
2. Please check to see that parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



### WARNING!








1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

8 MINUTES



## PARTS IDENTIFICATION

A	BASE		1PC
<del>A</del>	<del>SIDE</del> <del>BACK</del> CUSHION		2PCS
<del>A</del>	<del>AT</del> <del>ÖÖŠÖ</del> <del>BACK</del> CUSHION		1PC
<del>A</del>	<del>SEAT</del> CUSHION		3PCS
E	PILLOW		2PCS
F	PLASTIC LEG		4PCS
G	MIDDLE PLASTIC LEG		1PC

ITEM:509671




ASSEMBLY INSTRUCTIONS  
STEP 1





ITEM:509671

ASSEMBLY INSTRUCTIONS  
STEP 2




STEP 3 Assembly completed



ITEM: 509671



ASSEMBLY INSTRUCTIONS



Note: Dimension tolerance  $\pm 5\%$