

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

602274P POWER LIFT RECLINER

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A BACKREST 1PC


B CHAIR BASE 1PC

C POWER SOURCE 1PC


D ANTI-FALL BRACKETS 2PCS



ASSEMBLY INSTRUCTIONS STEP 1



Insert the Chair back (2) on the Chair seat (1). Gently push down until the back locks into position.






ASSEMBLY INSTRUCTIONS STEP 2

No.1: Wire connect the motor and the Control


Panel, No.2: Wire connect the motor and

transformer (A). No.3: Plug(B) connect the

transformer (A)









Find a small bag in the accessories box. Take out **Antifall Brackets*2(D)** from the small bag. Assemble the two Anti-fall Brackets as shown on the bottom of mechanism to avoid toppling and falling.

REMOTE INSTRUCTIONS





How to get footrest latch down and stand?



PAGE 6 OF 7

COASTERFURNITURE.COM

ITEM:**602274P** 37 42.5 9.5 18.5 25 21 39.75 39 34.5 22.5 64

Note: Dimension tolerance ±5%