




ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

503974
OTTOMAN

REVISION 0 : 04/17/2024

PAGE 1 OF 3

COASTERFURNITURE.COM

ITEM: 503974



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME


5 MINUTES

PARTS IDENTIFICATION

A OTTOMAN 1PC



B LEG 4PCS



HARDWARE IDENTIFICATION

1 LONG BOLT (M8*60MM) 8PCS




2 ALLEN WRENCH (5#) 1PC



ASSEMBLY INSTRUCTIONS

STEP 1




ITEM: **503974**



ASSEMBLY INSTRUCTIONS

PRODUCT DIMENSION



Note: Dimension tolerance $\pm 5\%$