


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

504837
SOFA

ITEM504837



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES


PARTS IDENTIFICATION

A	SOFA		1PC	B	LEG		5PCS
C	MIDDLE LEG		1PCS	D	PLUM PILLOW		2PCS
E	BEIGE PILLOW		1PCS				


HARDWARE IDENTIFICATION

1	BOLT		25PCS	2	ALLEN WRENCH (5#)		1PCS
---	------	--	-------	---	-------------------	--	------

STEP 1



STEP 2




ITEM:504837



ASSEMBLY INSTRUCTIONS

PRODUCT DIMENSION



Note: Dimension tolerance $\pm 5\%$