

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

REVISION 0 : 05/20/2018 REVISION 1 : 07/29/2019 REVISION 2 : 07/23/2020 REVISION 3 : 08/25/2022 REVISION 4 : 03/13/2023 REVISION 5 : 11/15/2023 REVISION 6 : 07/05/2024



PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: 2066 **ASSEMBLY INSTRUCTIONS**



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.			
	ASSEMBLY TIME	10 MINUTES	
PARTS IDENTIFICATION			
A	FRONT LEFT LEG FRAME		1 PC
В	FRONT RIGHT LEG FRAME		1 PC
С	BACK LEG FRAME		1 PC
D	BACK CUSHION		1 PC
E	SEAT CUSHION		1 PC
Z <u>HARDWARE IDENTIFICATION</u>			
1	BOLT (1/4" x 41mm)		8 PCS
2	SCREW (8# x 38mm)		4 PCS
3	CAP (1")		4 PCS
4	ALLEN WRENCH (4mm)		1 PC
NOTE: QUANTITIES SHOWN ARE FOR ONE CHAIR			
	_		

PAGE 2 OF 4



